

TOOLS REQUIRED

13mm or 14mm socket wrench to remove the front facing bumper bolts,

You DO NOT need to drill holes to mount the 3-point tire strap.



1. Begin by attaching the nylon transitional strap between the bumper bracket and bumper bracket bolt of the forward facing bumper bracket bolt hole.
2. The two lower leather straps have three adjustment hole settings which allowing you to adjust for various tire and rims sizes.



3. The upper strap end, with the metal clip, passes above, over the top and then behind the tire. In the next step, you will pull the metal clip through the center of the rim and attach it to the upper rim lip.



4. Once you pull the clip end of the leather strap through the center of the wheel rim, simply clip it to the lip of the inner wheel rim as shown.



5. Pull the top strap through the buckle and tighten.



6. All three straps have various hole adjustments that will allow you to fine tune the position of the straps so the round metal ring is always positioned directly in the center of the wheel rim.



7. The photo above shows the proper layout of the 3-point leather strap. Please note how the center metal ring aligns in the center of the wheel rim.